

Antenna Installation

Step 1. Weatherproof Cable Connectors

- 1st Layer: Electric Tape. Wrap from bottom upwards.
- 2nd Layer: Self Fusing Rubber Tape. Wrap from top downwards, then back up to top (2 layers).
- 3rd Layer: Electric Tape. Wrap from top downwards.



Step 2. Tie cable to the post

- Use the picture illustrated below to tie cable to the post.



Step 3. Dripping Loop

- Form correct Dripping Loop to protect the cable/connectors.

